

BOX FILLER ZR

The reverse box tipper is used to fill boxes. After the box is placed, the box tilts to the upper position and then the box is ready to be filled.



General description

The reverse box filler is used to fill boxes. After the box is placed, the box tilts to the upper position and then the box is ready to be filled. While the box is being filled, the box lowers. A sensor detects when the box needs to be stopped or lowered.

We have models are available in 120, 160, 180, and 240 cm belt widths. On demand, Safety fences with a sensor are included. The sensor detects if someone walks between the fences, which will stop the machine from functioning. The frame is made from painted mild steel and zinc plating. The bearings and drive/idle rollers are made of mild steel.



All dimensions in cm

		ZR 120	ZR 160	ZR 180	ZR 240
Α	Width of the machine	120	160	180	240

All capacities are indications based on experience from the past and depend on the agro climatic, soil and logistic conditions of the product, Allround VP does not guarantee any of these.

Characteristics

- ✓ Models are available in 120, 160, 180, and 240 cm belt widths
- ✓ The maximum width of the box is 120 cm
- ✓ The dept of the box is between 92 cm and 140 cm
- ✓ The height of the box is between 92 cm and 140 cm
- ✓ The angel of rotation is 80 degrees
- ✓ The box will stop rotating when the light sensor is activated

Options:

Material and treatment (frame)

Painted mild steel Frame is made from painted mild steel. The bearings and drive/idle rollers are from mild steel

Stainless steel Frame is made from stainless steel. The bearings and drive/idle rollers are from mild steel

■ Electrical control

No electric Motors only. Wiring, additional sensors and/or control panel are not included

Stand-alone Motors, necessary sensors, switch box and control box

Central control in line Motors and necessary sensors

Material and treatment (electrical panel)

Stainless steel The electrical panel is made from stainless steel


Safety fence

Fence Safety fences with a sensor are included. The sensor detects if someone walks between the fences

and will stop the functioning of the machine



ZR 160



For discussion only!
The dimensions are approximately.
We are free to resize and change the machines, when we deem if necessary.

